

Calibration and adjustment of RH instruments – pros and cons of different methods



There are many ways to approach the calibration and adjustment of relative humidity instruments. In a perfect world, all instruments would be checked and certified in accredited laboratories to the highest standards. In the real world, we must balance time, cost, technical requirements, expertise, and the unique needs of each specific user organization.

To help sort through different calibration approaches and methods, some of the most common will be described, along with their advantages and disadvantages. First, there are four concepts common to all calibration work that should be clarified:

Calibration – The act of comparing an instrument’s measurement to a known standard.

Adjustment – The act of adjusting an instrument to match a standard.

Calibration interval – The time elapsed between successive calibrations of an instrument.

Working standard – An instrument calibrated against either a secondary or primary standard and used to calibrate other instruments.

The word “calibration” is commonly, but not universally, interpreted to mean comparison and adjustment. To avoid misunderstanding, never assume that calibration includes an adjustment to an instrument.

Users often ask manufacturers for a recommended calibration interval. This is a reasonable starting point, but in practice, instrument performance may degrade at different rates depending of the use of the instrument, so the user must establish the calibration interval. The metrologist’s approach to this problem is to develop a history for the instrument by calibrating it (without adjustment) regularly until the measured drift exceeds allowable performance. The time between the “in service” date and the last acceptable calibration becomes the calibration interval. This interval is monitored with less frequent calibrations until an acceptable pattern of performance is demonstrated.

A working standard can be any instrument that is used to calibrate other instruments. It is not necessary that the working standard is the most accurate or repeatable of all possible instruments. The measurement performance of the working standard needs to be adequate for the intended use only. The important point is that the working standard is regularly calibrated against a secondary or primary standard and its performance is carefully monitored and documented.

The importance of temperature

Relative humidity is extremely temperature dependent. For the best possible calibration results, all apparatus used for calibration should be in temperature equilibrium. This means that the calibration environment should be at a stable temperature, and that the working standard and unit under test must be at the same temperature. If these conditions are not achieved, the calibration will have error caused by temperature gradient. In practice, this means that portable working standards must be given time to equilibrate when used in the field. This is particularly true when a standard that has been stored at room temperature is used in a process or environment that is warmer or cooler than room temperature.

One-point in-situ calibration

This method uses a working standard to calibrate a permanently installed field instrument without removing it from service. For instance, a technician may enter a room and use a hand-held device to check a wall mounted transmitter.

The main advantage of this method is its speed and ease of execution. There is no downtime for the field instrument and no additional labor required for removal and installation. A disadvantage to this approach is the lack of a second calibration point to indicate the correct dynamic response of the field instrument. If the measured conditions are stable within a small window, it may be adequate to gently breathe on the

sensor and observe response and recovery. If the measured conditions vary over a wide range, it is more desirable to have a multi-point calibration.

Multi-point field calibration

Two-point or three-point calibrations can be accomplished in the field with the help of humidity generating equipment, as long as the local environment is at a stable temperature. Known humidity levels can be created with a variety of devices, each with its own specific limitations and requirements. For example, a saturated salt bath is economical and easy to transport. However, sufficient time must be allowed for humidity equilibration after the bath is opened to atmosphere. Salt baths are not

considered traceable. Traceability can only be obtained by using an appropriate working standard in the bath with the unit under test.

The advantage of a multi-point field calibration is the ability to determine whether the field instrument operates correctly over the range of interest. Unfortunately, these calibrations are more difficult to perform than a simple, one-point, in-situ calibration. The technician needs more equipment, the field instrument usually has to come off-line, and the procedure can take an hour or more to complete. Field conditions are rarely optimum, so the highest level of accuracy is difficult to achieve.



Vaisala Humidity Calibrator HMK15 - an example of a saturated salt bath device.

In-house laboratory calibration

A number of organizations have dedicated in-house metrology and calibration capabilities. These are often found in organizations with many instruments to maintain and/or a need for “mission critical” measurements.

In-house laboratory calibration offers many advantages. The capabilities of the lab can be matched to the needs of the organization. In some cases, instrument users are completely relieved of responsibility for instrument performance. Metrologists can determine calibration intervals, and trained technicians perform work at the highest level in a controlled environment. Rapid turnaround time is possible, and customized “field service” can be made available to satisfy special requirements. Some convenience may be lost in large organizations where the calibration facilities are not located near the field instruments.

Commercial calibration laboratory

These are for-profit businesses that offer calibration services. Instruments are typically removed from service and sent to the laboratory for calibration. Some commercial labs will provide personnel to remove and install instruments, and some even offer on-site calibration in a portable laboratory.

Commercial labs are particularly useful for users with such a small number of instruments needing calibration that an investment in calibration equipment is not justified. These labs have varying levels of capability, but some can provide very high performance calibration, second only to national standards laboratories such as NIST. Commercial labs may specialize in humidity conditions that are difficult to achieve; for instance, extreme high or low humidities at extreme temperature ranges.

Users in search of a commercial lab should consider seeking a lab that is accredited. Accreditation means that the lab has been inspected and certified by an independent organization. The accreditation process results in an approved “scope” for the laboratory. The scope defines the parameters, ranges, and uncertainties that the laboratory provides. There are currently two accreditation bodies in the United States, NVLAP and A2LA. Each of these organizations maintains a web site listing the certified laboratories and their capabilities.

Download the Vaisala Calibration Book - [click here.](#)

VAISALA

For more information, visit www.vaisala.com or contact us at sales@vaisala.com

Ref. B210804EN-A ©Vaisala 2009
This material is subject to copyright protection, with all copyrights retained by Vaisala and its individual partners. All rights reserved. Any logos and/or product names are trademarks of Vaisala or its individual partners. The reproduction, transfer, distribution or storage of information contained in this brochure in any form without the prior written consent of Vaisala is strictly prohibited. All specifications – technical included – are subject to change without notice.